



XW-5.0~6.0K Series

5.0 kW / 6.0 kW

User Manual

Version 1.0

www.xwatt.in

STATEMENT

Copyright

Copyright © XWATT ENERGY PRIVATE LIMITED All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means without the prior written permission of XWATT ENERGY PRIVATE LIMITED

Trademarks



and other symbol or design (brand name, logo) that distinguishes services offered by Xwatt has been trademark protected. Any unauthorized use of the above stated trademark may infringe the trademark right.

Notice

Please note that certain products, features, and services mentioned in this document may not be within the scope of your purchase or usage. Unless otherwise specified in the contract, the contents, information, and recommendations presented in this document are provided "as is" by Xwatt. We do not provide any warranties, guarantees, or representations, whether express or implied.

The content of the documents is reviewed and updated as needed. However, occasional discrepancies may occur. Xwatt retains the right to make improvements or changes in the product(s) and the program(s) described in this manual at any time without prior notice.

The images included in this document are solely for illustrative purposes and may differ based on the specific product models.

For more detailed information, kindly visit the website of XWATT ENERGY PRIVATE LIMITED at www.xwatt.in.

Xwatt retains all rights for the final explanation.

About This Manual

Scope of Validity

This manual is an integral part of XW-5.0~6.0K series inverter. It describes the transportation, storage, installation, electrical connection, commissioning, maintenance and troubleshooting of the product. Please read it carefully before operating.

This manual is valid for the following inverter models:

- XW-5.0K
- XW-6.0K

Model description

XW-5.0K

1

2

Item	Meaning	Description
1	Product family name	"XW": a type of single phase inverter that supports grid connection of photovoltaic system.
2	Power	"5K": rated output power of 5 kW.

Target Group

The installation, maintenance and grid-related setting can only be performed by qualified personnel who:

- Are licensed and/or satisfy state and local regulations.
- Have good knowledge of this manual and other related documents.

Conventions

The symbols that may be found in this manual are defined as follows.

Symbol	Description
 DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION!	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury, device damage, power generation loss or unanticipated results.
NOTICE!	Provides tips for the optimal operation of the product.

Change History

Changes between document versions are cumulative. The latest version contains all updates made in previous versions.

Version 01 (Feb. 30, 2025)

Modified Chapter 6 Mechanical Installation (Revised the appearance of the inverter)

Version 00 (Nov. 10, 2024)

Initial release

Table of Contents

1	Safety	1
1.1	General Safety	1
1.2	Safety Instructions of PV, Inverter and Grid	1
1.2.1	Safety Instructions of PV	2
1.2.2	Safety Instructions of Inverter	2
1.2.3	Safety Instructions of Utility Grid	3
1.3	Additional Safety Instructions	3
2	Product Overview	6
2.1	System Introduction.....	6
2.2	Appearance	7
2.3	Supported Power Grid	8
2.4	Symbols on the Label and Inverter.....	9
2.5	Working Principle.....	10
2.5.1	Circuit Diagram	10
2.6	Working State.....	11
3	Transportation and Storage	12
4	Preparation before Installation.....	13
4.1	Selection of Installation Location	13
4.1.1	Environment Requirement	13
4.1.2	Installation Carrier Requirement.....	15
4.1.3	Clearance Requirement	15
4.2	Tools Requirement.....	16
4.3	Additionally Required Materials	17
5	Unpacking and Inspection	18
5.1	Unpacking.....	18
5.2	Scope of Delivery.....	19
6	Mechanical Installation	20
6.1	Dimensions for mounting	21
6.2	Installation procedures.....	21
7	Electrical Connection	24
7.1	Overview of Electrical Connection	24
7.1.1	Terminals of Inverter.....	24
7.1.2	Cable Connections of Inverter.....	25

7.2	PE Connection	26
7.3	AC Connection.....	28
7.4	PV Connection.....	32
7.5	COM/CT Port Connection.....	36
7.5.1	RS485 connection.....	36
7.5.2	Meter Connection.....	38
7.5.3	CT Connection.....	41
7.5.4	ShutDown.....	44
7.6	Dongle Port Connection.....	44
8	System Commissioning	46
8.1	Checking before Power-on.....	46
8.2	Powering on the System.....	46
8.3	Checking after Power-on.....	47
8.4	Commissioning.....	47
9	Operation on LCD.....	49
9.1	Introduction of Control Panel.....	49
9.2	Introduction of Main Interface.....	50
9.3	Introduction of Menu Interface.....	50
9.3.1	Status.....	51
9.3.2	Language.....	52
9.3.3	Date&Time.....	52
9.3.4	Setting.....	52
9.3.5	Meter Energy.....	53
9.3.6	Error Logs.....	53
9.3.7	About.....	54
9.4	Detailed Operation of Settings.....	55
10	Troubleshooting and Maintenance	68
10.1	Power off.....	68
10.2	Troubleshooting.....	68
10.3	Maintenance.....	72
10.3.1	Maintenance routines	72
10.3.2	Upgrading Firmware.....	73
11	Decommissioning	75
11.1	Disassembling the Inverter	75
11.2	Packing the Inverter	77
11.3	Disposing of the Inverter	77
12	Technical Data	78

13 **Appendix** 81

 13.1 Application of Generator 81

 13.1.1 Introduction of generator application 81

 13.1.2 Notice for generator application 81

 13.1.3 ATS control 81

 13.2 Application of EV-Charger 83

 13.2.1 Introduction of EV-Charger application 83

 13.2.2 Setting for EV-Charger 84

 13.3 Application of Parallel Connection 85

 13.3.1 Parallel System with Modbus Function 85

1 Safety

1.1 General Safety

The series inverter has been meticulously designed and thoroughly tested to comply with the relevant state and international safety standards. Nevertheless, like all electrical and electronic equipment, safety precautions must be observed and followed during the installation of the inverter to minimize the risk of personal injury and ensure a safe installation.

Please thoroughly read, comprehend, and strictly adhere to the comprehensive instructions provided in the user manual and any other relevant regulations prior to the installation of the inverter. The safety instructions in this document serve as supplementary guidelines to local laws and regulations.

Xwatt shall not be liable for any consequences resulting from the violation of the storage, transportation, installation, and operation regulations outlined in this document. Such consequences include, but are not limited to:

- Inverter damage caused by force majeure events, such as earthquakes, floods, thunderstorms, lightning, fire hazards, volcanic eruptions, and similar events.
- Inverter damage due to human causes.
- Inverter damage caused by strong vibrations from external factors before, during and after installation.
- Usage or operation of the inverter in violation of local policies or regulations.
- Failure to comply with the operation instructions and safety precautions provided with the product and in this document.
- Improper installation or usage of the inverter in unsuitable environmental or electrical conditions.
- Unauthorized modifications to the product or software.
- Inverter damage occurring during transportation by the customer.
- Storage conditions that do not meet the requirements specified in this document.
- Installation and commissioning performed by unauthorized personnel who lack the necessary licenses or do not comply with state and local regulations.

1.2 Safety Instructions of PV, Inverter and Grid

Save these important safety instructions. Failure to follow these safety instructions may result in damage to the inverter and injury or even loss of life.

1.2.1 Safety Instructions of PV

DANGER!

Potential risk of lethal electric shock associated with the photovoltaic (PV) system

- Exposure to sunlight can result in the generation of high DC voltage by PV modules, which can lead to electric shock causing severe injuries or even death.
- Never touch the positive or negative poles of the PV connecting device, and avoid touching both poles simultaneously.
- Do not ground the positive or negative poles of the PV modules.
- Only qualified personnel can perform the wiring of the PV modules.

WARNING!

- PV modules should have an IEC61730 class A rating.

WARNING!

- Make sure that the input DC voltage does not exceed the maximum DC input voltage specified for the inverter. Overvoltage can cause irreversible damage to the inverter, and such damage is not covered by the warranty.

1.2.2 Safety Instructions of Inverter

DANGER!

Potential risk of lethal electric shock associated with the inverter

- Only operate the inverter if it is in a technically faultless condition. Operating a faulty inverter may lead to electric shock or fire.
- Do not attempt to open the enclosure without authorization from Xwatt. Unauthorized opening of the enclosure will void the warranty and can result in lethal danger or serious injury due to electric shock.
- Make sure that the inverter is reliably grounded before any operation to prevent the risk of electric shock causing lethal danger or serious injury.
- Only qualified personnel can perform the installation, wiring, maintenance of the inverter by following this document and the related regulations.

WARNING!

- During operation, avoid touching any parts of the inverter other than LCD panel.
- Never connect or disconnect the AC and DC connector while the inverter is running.
- Prior to conducting any maintenance, turn off the AC and DC power and disconnect them from the inverter. Wait for 5 minutes to fully discharge the energy.

 WARNING!

- Potential danger of scalding due to the hot enclosure of the inverter
- Avoid touching the inverter while it is running, as it becomes hot during operation and may cause personal injuries.

 WARNING!

- Use insulated tools when installing the device, and always wear personal protective equipment during installation and maintenance.

 CAUTION!

- Make sure that children are supervised to prevent them from playing with the inverter.
- Pay attention to the weight of the inverter and handle it properly to avoid personal injuries.

NOTICE!

- Keep all product labels and the nameplate on the inverter clearly visible and well-maintained.

1.2.3 Safety Instructions of Utility Grid

NOTICE!

- Only connect the inverter to the grid with the permission of the local utility grid company.

1.3 Additional Safety Instructions

Surge protection devices (SPDs) for PV installation

 DANGER!

- Over-voltage protection with surge arresters should be provided when the PV power system is installed. The grid connected inverter is fitted with SPDs in both PV input side and MAINS side.

Direct or indirect lightning strikes can cause failures. Surge is the main cause of lightning damage to most devices. Surge voltage may occur at photovoltaic input or AC output, especially in remote mountain areas where long distance cable is supplied.

Please consult professionals before installing SPDs.

The external lightning protection device can reduce the influence of direct lightning strike, and the lightning protection device can release surge current to the earth.

If the building installed with external light protection device is far away from the inverter location, in order to protect the inverter from electrical and mechanical damage, the inverter should also install an external lightning protection equipment.

In order to protect DC system, the level 2 surge protection equipment is needed between DC cable of inverter and photovoltaic equipment module.

In order to protect the AC system, the level 2 surge protection equipment should be installed at the AC output, located between the inverter and the grid. Installation requirements must comply with IEC61643-21 standard.

All DC cables shall be installed in a distance as short as possible, and the positive and negative cables of the same input need to be bundled together to avoid causing loops in the system. Minimum distance installation and binding requirements also apply to auxiliary grounding and shielding grounding conductors.

Anti-Islanding Effect

The islanding effect means that when the power grid is cut off, the grid-connected power generation system fails to detect the power outage and still supplies power to the power grid. This is very dangerous for the maintenance personnel and the power grid on the transmission line. The inverter's use frequency shift method to prevent islanding effect.

PE Connection and Leakage Current

The inverter has an integrated Type-B Residual Current Monitoring Unit (RCMU) in order to protect against possible electrocution and fire hazard in case of a malfunction in the PV array, cables or inverter. There are 2 trip thresholds for the RCM as required for certification (IEC 62109-2:2011).

The default value for electrocution protection is 30 mA, and for slow rising current is 300 mA. If an external RCD is required by local regulations, verify the type of RCD required. It is recommended to choose a Type-A RCD with the rating residual current of 300 mA. When required by local regulations, the use of a Type-B RCD is permitted.



- High leakage current!
- Earth connection essential before connecting supply.

A faulty ground connection can result in equipment failure, personal and death injuries, and electromagnetic interference. Ensure correct according to grounding to IEC62109 and conductor diameter according to STANDARD specification. Do not connect the grounding end of the equipment in series to prevent multi-point grounding. Electrical appliances must be installed in accordance with the wiring rules of each country.

For United Kingdom

The installation that connects the equipment to the supply terminals shall comply with the requirements of BS 7671. Electrical installation of PV system shall comply with requirements of BS 7671 and IEC 60364-7-712. All protective devices cannot be changed.

User shall ensure that equipment is so installed, designed and operated to maintain at all times compliance with the requirements of ESQCR22(1)(a).

2 Product Overview

2.1 System Introduction

The XW-5.0~6.0K series inverter is a transformerless single-phase PV grid-connected inverter which is designed to convert the direct current generated from the PV modules into grid-compatible AC current and feeds the AC current to the utility grid. It supports various intelligent solutions such as load management, etc. to achieve efficient and economical energy utilization.

Table 2-1 System item description

Item	Description
XW-5.0~6.0K series (the device covered in this manual)	The XW-5.0~6.0K series is a grid-connected inverter that supports grid connection of a photovoltaic system.
PV modules	PV modules work in MPPT mode. The maximum number of MPPT is one for XW-5.0~6.0K inverters.
Meter/CT	The meter/CT is used by the inverter for import / export or consumption readings.
EV-Charger (supported)	The series inverter can communicate with Xwatt EV-Charger to form an intelligent photovoltaic, and EV charging energy system, thus maximizing the utilization of photovoltaic energy. Please refer to "14.2 Application of EV-Charger" for specific wiring and setting.
Generator (supported)	Xwatt PV-Genset solution ensures optimum interaction between the photovoltaics and diesel generator, which saves fuel, lowers energy costs and ensures a stable and reliable power supply. Please refer to "14.1 Application of Generator" for specific wiring and setting.
Grid	230 V grid is supported.

System Overview




Figure 2-1 System overview diagram

NOTICE!

- The parallel system with Modbus function and the EV-Charger application can not be realised at the same time, choose only one of these applications at a time.

2.2 Appearance




Figure 2-2 Appearance

Table 2-1 Description of appearance

Item	Description
Nameplate	Nameplate clearly identifies the device type, serial number, specific DC / AC parameters, certification, etc.
LCD panel	Including screen, indicators and keys. Screen displays the information; indicators indicate the status of inverter. Keys are used to perform the parameter setting.
Grounding point	Grounding point is used for PE connection.
Electrical connection area	Including AC terminals, communication terminals, etc.

2.3 Supported Power Grid

There are different ways of wiring for different grid systems. TT / TN-S / TN-C-S are shown as below:




Figure 2-3 Supported power grid-TT




Figure 2-4 Supported power grid-TN-S




Figure 2-5 Supported power grid-TN-C-S

2.4 Symbols on the Label and Inverter

Table 2-2 Description of symbols

Symbol	Description
	CE mark. The inverter complies with the requirements of the applicable CE guidelines.
	Beware of hot surface. Do not touch a running inverter, as the inverter becomes hot during operation!
	Risk of electric shock. High voltage exists after the inverter is powered on!
	Risk of danger. Potential hazards exist after the inverter is powered on!
	Read the enclosed documentations.
	Do not dispose of the inverter together with household waste.
	Do not operate this inverter until it is isolated from mains and on-site PV generation source.
	Danger of high voltage. Do not touch live parts for 5 minutes after disconnection from the power sources.

2.5 Working Principle

2.5.1 Circuit Diagram

The inverter is equipped with single-channel MPPT for DC input. The inverter unit converts direct current into alternating current that meets the requirements of the power grid and feeds it into the power grid. The principle design of inverter is shown in the figure below:




Figure 2-6 Circuit diagram for XW-5.0~6.0K series inverter

2.6 Working State

The series inverter has Waiting, Checking, and Normal states.

Table 2-3 Description of working state

State	Description
Waiting	• The inverter is waiting to check when the DC input voltage from panels is greater than the start-up voltage but less than the lowest operating voltage.
Checking	• Inverter will check DC input environment automatically when DC input voltage from the PV panels exceeds the lowest operating voltage and PV panels have enough energy to start inverter.
Normal	• Inverter begins to operate normally when the blue light is constantly on. • Meanwhile the inverter outputs power to the grid (if condition permits), LCD displays the present output power.

3 Transportation and Storage

If the inverter is not put into use immediately, the transportation and storage requirements need to be met:

Transportation

- The inverter must be transported in its original packaging. Xwatt will not be held responsible for any damage to the inverter caused by improper transportation or by transportation after it has been installed.
- Observe the caution signs on the packaging of inverter before transportation.
- Pay attention to the weight of the inverter. Carry the inverters by the required number of personnel as specified by local regulations.(gross weight of XW-5.0~6.0K: 9.0 kg)
- Wear protective gloves when carrying the equipment by hand to prevent injuries.
- When lifting up the inverter, handle with care. Keep the inverter horizontal in case of falling down.




Figure 3-1 Caution signs on the packaging

Storage

- The inverter must be stored indoors.
- Do not remove the original packaging material and check the outer packaging material regularly.
- The storage temperature should be between -30°C and +70°C. The relative humidity should be between 60%RH and 65%RH.
- Stack the inverter in accordance with the caution signs on the inverter carton to prevent their falling down and device damage. Do not place it upside down.

4 Preparation before Installation






4.1 Selection of Installation Location

The installation location selected for the inverter is quite critical in the aspect of the guarantee of machine safety, service life and performance. It has the IP66 ingress protection, which allows it to be installed outdoor. The installation position shall be convenient for wiring connection, operation and maintenance.

4.1.1 Environment Requirement

Make sure the installation environment meets the following conditions:

- The ambient temperature: -25°C to $+60^{\circ}\text{C}$.
- The relative humidity shall be between 0-100%RH.
- Do not install the inverter in the areas where the altitude exceeds 4000 m.
- Install the inverter in a well-ventilated environment for heat dissipation. It is recommended to install an awning over the inverter if it is installed on a support outdoor.
- Do not install the inverter in areas with flammable, explosive and corrosive materials or near antennas.
- Avoid direct sunlight, rain exposure and snow accumulation.



NOTICE

- For outdoor-installation, precautions against direct sunlight, rain exposure and snow accumulation are recommended.
- Exposure to direct sunlight raises the temperature inside the device. This temperature rise poses no safety risks, but may impact the device-performance.

- Install the inverter at least 500 meters away from the coast and avoid sea breeze directly hit.




Figure 4-1 Recommended installation position




Figure 4-2 Incorrect installation position

NOTICE!

- For the installation of the whole system, please refer to the specific environment requirement of each unit.

4.1.2 Installation Carrier Requirement

The installation carrier must be made of a non-flammable material, such as solid brick, concrete, etc. and be capable of supporting the weight of the inverter and suitable of the dimensions of the inverter. If the wall strength is not enough (such as wooden wall, the wall covered by a thick layer of decoration), it must be strengthened additionally.




Figure 4-3 Installation carrier requirement

4.1.3 Clearance Requirement

When planning installation space, it is important to consider the bending radius of the wires and the length of external devices (if any).

To guarantee proper heat dissipation and ease of disassembly, the minimum space around the inverter must meet the standards indicated below.

For installations with multiple inverters, make sure to leave a minimum space of 30 cm between each inverter. In areas with high ambient temperatures, increase the clearances between the inverters and provide adequate fresh air ventilation if feasible.




Figure 4-4 Clearance requirement for single inverter







Figure 4-5 Clearance requirement for multiple inverters

4.2 Tools Requirement

Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site. Please note that the tools used must comply with local regulations.





4.3 Additionally Required Materials

Table 4-1 Additionally required wires

No.	Required Material	Type	Size
1	PV cable	 Dedicated PV wire withstand voltage 600 V	Cross sectional area: 4~6 mm ²
2	AC cable	 Three-core copper wire	Cross sectional area: 5~6 mm ² * The cross-sectional area of PE line should be the same as that of L/N line.
3	Communication cable	 Network cable CAT5	Outer diameter: Ø2~6 mm
4	Additional PE cable	 Conventional yellow and green wire	Cross sectional area: 5~6 mm ² * The cross-sectional area of PE line should be the same as that of L/N line.

Table 4-2 Circuit breaker recommended

Model	XW-5.0K	XW-6.0K
Circuit breaker 	32 A	32 A

5 Unpacking and Inspection

5.1 Unpacking

- The inverter undergoes 100% testing and inspection before delivery. However, damages may still occur during transportation. Before unpacking, please carefully check the external packaging for any signs of damage, such as punctures or cracks.
- Unpacking the inverter according to the following figure.





Figure 5-1 Unpacking the inverter

- Properly handle all the packaging materials in case they may be reused for storage and transportation of the inverter in the future.
- Upon opening the package, check whether the inverter is intact and whether all accessories are included. If any damage is found or any parts are missing, contact your dealer immediately.

5.2 Scope of Delivery



*Refer to the actual delivery for the optional accessories.

Item No.	Items	Quantity	Remark
/	Inverter	1 pc	
/	Bracket	1 pc	
A	Documents	/	
B	Self-tapping screw	2 pcs	For bracket installation
C	Expansion tube	2 pcs	For bracket installation
D	Expansion bolt	2 pcs	For bracket installation
E	Earth terminal	1 pc	
F	M6*L12 screw	1 pc	For securing the inverter with bracket
G	RJ45 terminal	1 pc	For PE connection
H	Positive PV connector	1 pc	
I	Positive PV pin contact	1 pc	
J	Negative PV connector	1 pc	
K	Negative PV pin contact	1 pc	
L	AC connector	1 pc	
M	Removal tool for AC connector	1 pc	
N	Allen key	1 pc	
/	Dongle (optional)	1 pc	

6 Mechanical Installation

! WARNING!

- Only qualified personnel are allowed to perform the mechanical installation in accordance with local laws and regulations.
- Check the existing power cables or other piping in the wall to prevent electric shock or other damage.
- Use insulated tools and wear personal protective equipment throughout the installation and maintenance process.

! CAUTION!

- During installation, always be cautious about the weight of the inverter. Improper lifting or dropping of the inverter may result in personal injury.

NOTICE!

- Install the inverter at a maximum back tilt of 5 degrees and avoid it being forward tilted, side tilted, or upside down.




Figure 6-1 Correct installation




Figure 6-2 Incorrect installation

6.1 Dimensions for mounting

Before installation, check the dimensions of the wall mounting bracket and ensure that enough space is reserved for the installation and heat dissipation of the entire system.




Figure 6-3 Dimensions 1 (Unit: mm)




Figure 6-4 Dimensions 2 (Unit: mm)

6.2 Installation procedures

Step 1: Horizontally align the bracket with the wall, adjust the position of the bracket with a spirit level until the bubble stays in the middle, and then mark holes.




Figure 6-5 Marking the holes

Step 2: Set the bracket aside and drill holes with $\varnothing 10$ drill bit. The depth of the holes should be 60 mm. Knock the expansion tubes (part C) into the holes.




Figure 6-6 Drilling holes (Unit: mm)

Step 3: Attach the bracket on the wall again. Use a screwdriver to secure the bracket by tightening screws into the expansion tubes.




Figure 6-7 Securing the wall mounting bracket

Step 4: Hang the inverter over the bracket, move the inverter close to it, slightly lay down the inverter, and make sure the inverter is well fixed on the bracket. If the inverter needs to be temporarily placed on the ground, use foam or other protective materials to protect it against potential damages.




Figure 6-8 Mounting the inverter

Step 5: Use a M6*L12 screw to secure the left side of inverter with bracket.




Figure 6-9 Secure the inverter

7 Electrical Connection

DANGER!

- Before electrical connection, make sure the DC switch and AC breaker are disconnected. Otherwise, the high voltage may cause electric shock, resulting in severe personal injuries or even death.

WARNING!

- Only qualified personnel are allowed to perform the electrical connection following local laws and regulations.
- Strictly follow the instructions of this manual or other related documentation for electrical connection. Inverter damages caused by incorrect wiring are not covered by the warranty.
- Use insulated tools and wear personal protective equipment throughout the electrical connection process.

7.1 Overview of Electrical Connection

7.1.1 Terminals of Inverter




Figure 7-1 Terminals of Inverter

Table 7-1 Description of terminals

Item	Description	Decisive voltage class
A	DC input terminal	DVC-C
B	Dongle	DVC-A
C	COM/CT	DVC-A
D	AC output terminal	DVC-C
E	Ground terminal	-

7.1.2 Cable Connections of Inverter




Figure 7-2 Cable connections of inverter

Table 7-2 Descriptions of connected part

Item	Part	Description	Source
A	PV module	A PV string is composed of the PV modules connected in series.	Prepared by user
B	(Optional) Xwatt dongle	Xwatt Pocket series dongle like Pocket WiFi V3.0.	Purchased from Xwatt
C	(Optional) Xwatt communication device	Xwatt CT and Meter are supported. Select the device as needed.	Purchased from Xwatt

Item	Part	Description	Source
D	AC switch	Select an appropriate AC switch according to the local regulations to ensure the inverter can be securely disconnected from the grid when an emergency occurs. The current of AC switch: 32 A.	Prepared by user
E	PE cable	Select an appropriate PE cable according to the local regulations to ensure the inverter can be well grounded to the earth.	Prepared by user

Table 7-3 Descriptions of cables

Item	Cable	Type and specifications	Source
1	DC input power cable	Refer to "4.3 Additionally Required Materials".	Prepared by user
2	RS485 communication cable		Prepared by user
3	AC output cable		Prepared by user
4	PE cable		Prepared by user

7.2 PE Connection

The inverter must be reliably grounded. The PE connection point has been marked with . It is recommended to connect the inverter to a nearby grounding point.

PE connection procedures

Step 1: Strip the insulation of the PE cable to an appropriate length.




Figure 7-3 Stripping the PE cable

Step 2: Pull the heat-shrink tubing over the PE cable and insert the stripped section into the earth terminal (part D).




Figure 7-4 Installing the tubing and OT terminal

Step 3: Crimp it with crimping tool, pull the heat-shrink tubing over the stripped section of the earth terminal and use a heat gun to shrink it so that it can be firmly contacted with the terminal.




Figure 7-5 Crimping the cable




Figure 7-6 Shrinking the tubing

Step 4: Remove the PE screw on the inverter with cross screwdriver.




Figure 7-7 Uninstalling the screw

Step 5: Connect the assembled PE cable to the grounding point of the inverter, and secure it with the original screw. (Torque: $2.0 \pm 0.1 \text{ N}\cdot\text{m}$)




Figure 7-8 Securing the PE cable

7.3 AC Connection

NOTICE!

- Before connecting the inverter to the grid, approval must be received by local utility as required by national and state interconnection regulations.

Requirements for AC connection

- Grid voltage requirement
 - » The grid voltage must be within the permissible range. The inverter is suitable for rated voltage 230 V, frequency 50 Hz. Other technical requests should comply with the requirement of the local power grid.
- Residual Current Device (RCD)
 - » The inverter has an integrated Type-B Residual Current Monitoring Unit (RCMU). The inverter does not require an external residual-current device

when operating. If an external RCD is required by local regulations, It is recommended to use a Type-A RCD with the value of 300 mA.

- AC breaker
 - » An AC breaker that matches the power of the inverter must be connected between the inverter output and the public grid, and each inverter must be equipped with an independent breaker or other load disconnection unit to ensure the safe disconnection from the power grid. For specific information on the AC breaker for Grid, refer to the following Table 7-4.
- Load
 - » It is prohibited to connect any load between the inverter and the AC breaker.

Table 7-4 Cable and micro-breaker recommended

Item	XW-5.0K	XW-6.0K
L, N cable	4-6 mm ²	4-6 mm ²
PE cable	5-6 mm ²	5-6 mm ²
Micro-breaker	32 A	32 A

NOTICE!

- Copper cable is recommended, if you use aluminium cable, please consult the inverter manufacturer.
- The parameter varies because of different environment and material.
- The cross-sectional area of PE line should be the same as that of L/N line.
- Please choose appropriate cable and micro-breaker according to the local laws and regulations.

Wiring procedures



DANGER!

- Check the grid voltage and compare with the permissive voltage range (refer to "13 Technical Data").
- Disconnect the circuit-breaker from all the phases and secure against re-connection.

Step 1: Strip L and N wires to 52.5 mm and the PE wire to 55 mm. Use the crimping pliers to strip 6 mm of insulation from all wire ends as below.




Figure 7-9 Strip the L, N, PE wires

Step 2: The AC connector (part J) provided in the packing list includes A and B. Separate A into component 1 and component 2.




Figure 7-10 Separate component A




Figure 7-11 Separated AC connector

Step 3: Slide the component 1 and component 2 onto the AC cable.




Figure 7-12 Slide component 1&2 on to AC cable

Step 4: Insert the stripped end of L, N and PE wires into the corresponding hole in the B, and then tight each screw (to tight each wire in place). (Allen key (part L); Torque: $0.5 \pm 0.1 \text{ N}\cdot\text{m}$).




Figure 7-13 Insert wires in to the corresponding holes

Step 5: Tighten A with component 2. Screw down the component 1 tightly. (torque: $3 \pm 0.3 \text{ N}\cdot\text{m}$)




Figure 7-14 Screw down component 1

Step 6: Connect the AC plug to the inverter. When you heard a "click", the AC is successfully connected.




Figure 7-15 Connect AC plug to the inverter

NOTICE!

- Make sure that the buckles are on the same side.

7.4 PV Connection

⚠ DANGER!

- When exposed to the sunlight, PV modules will generate lethal high voltage. Please take precautions.
- Before connecting the PV modules, make sure that both DC switch and AC breaker are disconnected, and that the PV module output is securely isolated from the ground.

⚠ WARNING!

- To mitigate the risk of fire, it is crucial to utilize a dedicated crimping tool specifically designed for PV installations to ensure secure and reliable connections.

⚠ CAUTION!

- Power is fed from more than one source and more than one live circuit.
- In order to save cable and reduce the DC loss, we suggest installing the inverter near PV modules.

Requirements for PV connection

- Open circuit voltage and operating voltage
 - » The open circuit voltage of each module array cannot exceed the maximum PV input voltage (refer to "13 Technical Data") of the inverter. Otherwise, the inverter may be damaged.
 - » The operating voltage of PV modules must be within the MPPT voltage range (refer to "13 Technical Data") of the inverter. If the operating voltage of PV modules exceeds the MPPT voltage range, the inverter will prompt a **BUS Fault** alarm. Consider the impact of low temperature on the voltage of the photovoltaic panels, as lower temperatures tend to result in higher voltages.

Table 7-5 Max. DC voltage limitation

Model	XW-5.0K	XW-6.0K
Max. DC voltage (V)	600	600

- PV module
 - » The PV modules within the same MPPT channel are of the same brand.
 - » The positive or negative pole of the PV modules should not be grounded.
 - » The positive cables of the PV modules must be connected with positive DC connectors.
 - » The negative cables of the PV modules must be connected with negative DC connectors.

Wiring procedures

Step 1: Make sure that the DC switch is off, then choose 4-6 mm² wire to connect the PV module.

Step 2: Strip 7 mm of insulation from the wire end by using the wire stripper crimping tool.




Figure 7-16 Stripping the PV cable

NOTICE!

- MC4 crimping tool recommended: model : H4TC0001; manufacturer: Amphenol

Step 3: Insert striped wire into pin contact (part G and I) and ensure all conductor strands are captured in the pin contact.




Figure 7-17 Inserting the PV pin contact

Step 4: Make sure the the PV cable and PV pin contact (part E) are of the same polarity. Crimp it with crimping tool for PV terminal. Pay attention to the crimping position.




Figure 7-18 Crimping the terminal

Step 5: Separate the DC connector (part F and H) as two parts: the plug and the cable nut. Insert the wire into plug forcibly, when a "Click" is heard or felt, the pin contact assembly is seated correctly.




Figure 7-19 Threading the PV cable

Step 6: A "Click" will be heard if it is connected correctly. Gently pull the cable backward to ensure firm connection. Tighten the swivel nut clockwise. Verify that the PV connectors have the correct polarity before connection.




Figure 7-20 Securing the PV cable

Step 7: Use a voltage measuring device which complies with the local regulation to measure the positive and negative voltage of the assembled PV connectors. Make sure the open circuit voltage does not exceed the Max. DC voltage (refer to "[13 Technical Data](#)").




Figure 7-21 Measuring the voltage of PV connectors

NOTICE!

- If the voltage reading is negative, it indicates an incorrect DC input polarity. Please check if the wiring connections on the measuring device are correct or PV connectors are not mistakenly connected.

Step 8: Connect the assembled PV connectors to the corresponding terminals until there is an audible "Click". The PV+ on the string side must be connected to the PV+ on the inverter side, and the PV- on the string side must be connected to the PV- on the inverter side.




Figure 7-22 Connecting the PV cable

7.5 COM/CT Port Connection

The inverter provides a COM/CT port, through this port the inverter can communicate with a computer, meter, CT or other devices to achieve various functions.

7.5.1 RS485 connection

RS485 is one standard communication interface which can transmit the real-time data from inverter to PC or other monitoring equipment.




Figure 7-23 RS485 connection

Table 7-6 PIN definition of RS485

PIN	1	2	3	4	5	6	7	8
Definition	X	X	X	485_A	485_B	X	X	X

RS485 connection wiring procedure

Step 1: Firstly unscrew the screw from the COM/CT port. (PH1 cross screwdriver. Torque: $1.0 \pm 0.1 \text{ N}\cdot\text{m}$)




Figure 7-24 Disassemble COM/CT port

Step 2: Prepare a communication cable and strip 10~15 mm of the insulation part. Thread the communication cable through the waterproof connector, then insert it into the RJ45 terminal (part E) following the PIN definition rule.




Figure 7-25 Insert the communication cable

Step 3: Crimp the RJ45 terminal with the crimping plier.




Figure 7-26 Crimp the RJ45 terminal

Step 4: Insert the RJ45 terminal into the COM/CT port of the inverter, screw down the screw on the port and tighten the waterproof connector.




Figure 7-27 Insert the terminal into COM/CT port

7.5.2 Meter Connection

The inverter should work with an electric meter or current transformer (CT for short) to monitor household electricity usage. The electricity meter can transmit the relevant electricity data to the inverter or platform.

With this single phase meter working together with the inverter, you can monitor the energy to grid and from grid through the whole day and achieve the export control function with a higher accuracy.

⚠ CAUTION!

- Smart meters must be authorized by our company. Unauthorized meter may be incompatible with the inverter, thereby resulting in inverter damage and working mode malfunction. Xwatt will not be responsible for the impact caused by the use of other appliances.
- Please make PE connection for Meter if the meter has ground terminal.

Meter connection procedure

- For meter with CT




Figure 7-28 Wiring Diagram-Meter with CT

- For meter without CT




Figure 7-29 Wiring Diagram-Meter without CT

Table 7-7 PIN definition of meter

PIN	1	2	3	4	5	6	7	8
Definition	X	X	X	485_A	485_B	X	X	X

Please see *the Quick Guide or User Manual of Single Phase Meter* for details.

7.5.3 CT Connection

The inverter should work with an electric meter or current transformer (CT for short) to monitor household electricity usage. The electricity meter or CT can transmit the relevant electricity data to the inverter or platform.

CAUTION!

- Xwatt will not be responsible for the impact caused by the use of other appliances.

NOTICE!

- Do not place the CT on the N wire or ground wire.
- Do not put CT on the N wire and L wire at the same time.
- Do not place the CT on the side where the arrow points to the inverter.
- Do not place the CT on non-insulated wires.
- The cable length between CT and inverter should not exceed 25 meters.
- After CT is connected, prevent the CT clip from falling off.
- It is recommended to wrap the CT clip around in circles with insulating tape.

CT connection diagram

- CT connection diagram




Figure 7-30 CT connection diagram

Table 7-8 PIN definition of CT

PIN	1	2	3	4	5	6	7	8
Definition	CT+	X	X	X	X	X	X	CT-

CT wiring procedure

Step 1: Firstly unscrew the screw from the COM/CT port. (PH1 cross screwdriver. Torque: $1.0 \pm 0.1 \text{ N.m}$)




Figure 7-31 Disassemble COM/CT port

Step 2: Prepare a communication cable and strip the insulation from it.

Step 3: Thread the communication cable through the waterproof connector, then insert it into the connector following the PIN definition rule.

Step 4: Insert the RJ45 terminal of CT into the COM/CT port on the inverter, and screw down the screw cap tightly.




Figure 7-32 Insert the communication cable




Figure 7-33 Crimp the RJ45 terminal




Figure 7-34 Insert the terminal into COM/CT port

- Step 5:** Make sure the CT is installed in the right direction: The arrow on the current sensor must point to the power grid.
- Step 6:** Clip the CT clamp on L line from the home main meter box side.
- Step 7:** Use the insulating tape to prevent CT from falling off.

7.5.4 ShutDown

When this function is enabled, and PIN 2 and PIN7 are wired, the inverter will be turned off. The user should follow the PIN rules below and cooperate with external equipment when using it.

Table 7-9 PIN definition of DRM

PIN	1	2	3	4	5	6	7	8
Definition	X	Shutdown	X	X	X	X	+3.3V	X

ShutDown shares the terminal with RS485/ Meter communications. For the connection steps of the ShutDown, user can refer to the above RS485 connections.

Please refer to ["Shutdown"](#) for specific settings.

7.6 Dongle Port Connection

The inverter provides a Dongle terminal, which can transmit data of the inverter to the monitoring website via Pocket WiFi V3.0 (Optional).

Monitoring connection diagram




Figure 7-35 Wi-Fi mode connection diagram

Monitoring wiring procedure

- a. Plug the dongle into the inverter.




Figure 7-36 Dongle connection procedure

CAUTION!

- The buckles on the inverter and dongle must be on the same side. Otherwise, the dongle may be damaged.

NOTICE!

- The distance between the router and the inverter must be no more than 100 meters. If there are walls in between, the distance must be no more than 20 meters.
- For locations where Wi-Fi signals are weak, install a Wi-Fi signal booster.

NOTICE!

- For details on Wi-Fi configuration, see *Pocket WiFi V3.0 Installation Manual*. You can configure Wi-Fi only after the inverter is powered on.

8 System Commissioning

8.1 Checking before Power-on

No.	Item	Checking details
1	Installation	The inverter is installed correctly and securely. Other device (if any) is installed correctly and securely.
2	Wiring	All DC, AC cables and communication cables are connected correctly and securely; The meter/CT is connected correctly and securely. The ground cable is connected correctly and securely;
3	Breaker	All the DC breakers and AC breakers are OFF;
4	Connector	The external AC and DC connectors are connected; The connectors on the AC terminal are connected correctly and securely.
5	Unused terminal	Unused terminals and ports are locked by waterproof caps.
6	Screw	All the screws are tightened.

8.2 Powering on the System

Step 1: Turn on the AC breaker.




Figure 8-37 Turn on the AC breaker

Step 2: When the photovoltaic panel generates enough power, the inverter will start automatically. The inverter will go Waiting, Checking and Normal status in sequence.

Waiting: The auxiliary power supply of the inverter has been started and the inverter is successfully connected to the mains and waiting for the PV side to meet the working requirement.

Checking: The inverter will automatically detect the DC input. When the photovoltaic panel has enough energy to start the inverter, the inverter will perform self-checks, such as insulation detection, RCD tests.

Normal: The inverter starts to work normally, the operation indicator light is steady in blue. At the same time, the power is fed back to the grid, and the LCD displays the output power.



WARNING!

- Power to the unit must be turned on only after installation work has been completed.
- All electrical connections must be carried out by qualified personnel in accordance with legislation in force in the country concerned.

NOTICE!

- Please set the inverter according to local requirements.

8.3 Checking after Power-on

Step 1: Check the status of LED indication and LCD screen, the LED indication should be blue and the LCD screen should display the main interface. If the LED indication is not blue, please check the following conditions:

- » All the connections are correct.
- » All the external disconnect switches are closed.
- » The wiring on the DC side is intact.
- » The external DC switch is turned on.

8.4 Commissioning

You can adjust setpoints for power quality response modes and grid protection settings if required.

After commissioning, you can view the following settings through the LCD of the inverter after commissioning: Region settings (and setpoints) for grid protection settings Region settings (and setpoints) for power quality response modes.

NOTICE!

- Once settings are selected at commissioning they are locked to view only.

NOTICE!

- Password should not be readily available – if you need that, you can find the password that either in a separate maintenance/service manual or available from manufacturer/importer upon request.

9 Operation on LCD

9.1 Introduction of Control Panel




Figure 9-1 Control Panel

- In a normal state, the **Power, Pgrid, Today, and Total** information will be displayed. You can press the keys to switch information.
- In an error state, the fault message and error code will be displayed, please refer to ["11.2 Troubleshooting"](#) for corresponding solutions.

Table 9-1 Definition of indicators

LED indicator	Status	Definition
 Operating	 Light on	The inverter is in a normal state.
	 Blinking	The inverter is in a waiting or checking state.
 Error	 Light on	The inverter is in a fault state.

Table 9-2 Definition of keys

Key	Definition
 UP/ESC key	Short press to move cursor up or increase value. Long press to return from the current interface function.
 DOWN/Enter key	Short press to move cursor down or decrease value. Long press to confirm and change parameters.

9.2 Introduction of Main Interface

The main interface is the default interface, the inverter will automatically jump to this interface when the system starts up successfully or is not operated for a period of time.



The first line shows the following information:

Power means the timely output power;

Pgrid means the power export to or import from the grid (Positive value means the energy feeds into the grid, negative value means the energy used from the grid);

Today means the energy generated within the day;


Total means the energy generated until now.

The second line shows the running status of the inverter.

Normal means the inverter is in normal status.

When the inverter is in fault status, the error code and information will be displayed.

9.3 Introduction of Menu Interface



When the inveter shows the default interface, long press **Enter** key to enter the menu interface. There are seven submenus in the menu that can be selected for relevant operations.



Status: Display the real-time value of the inverter, including **Grid** and **Solar**.


Language: Set the language displayed on the inverter.

Date&Time: Set the date and time.

- Settings:** Set the parameters of the inverter.
- Meter Energy:** Display the import and export energy information of the inverter.
- Error Logs:** Display the error logs of the inverter.
- About:** Display the information about the inverter.

9.3.1 Status


Status display the real-time value of the inverter, including **Grid** and **Solar**.
Short press Up and Down to select and long press Down to confirm the selection, long press Up to return to Menu.



Grid


This status shows the current condition of the AC output port of the inverter, such as voltage, current, output power and grid power. This status includes 5 parameters: **U**, **I**, **F**, **Pout**, **Pgrid**.

- » **U:** The voltage of the AC output of the inverter.
- » **I:** The current of the AC output of the inverter.
- » **F:** The frequency of the AC output of the inverter.
- » **Pout:** A parameter that measures the output power of the inverter.
- » **Pgrid:** A parameter that measures power export to or import from the grid. Positive value means the power feeds into the grid, negative value means the power used from the grid.




Solar

This parameter shows the real time PV condition of the system, such as input voltage, current and power of the PV input. This status includes 3 parameters: **U1, I1, P1**.



9.3.2 Language

English is the default system language.



9.3.3 Date&Time

You can set the current date and time of the installation site. The display format is "2024-01-01 00:00", in which the first four numbers represent the year (e.g. 2000~2099); the fifth and sixth numbers represent the month (e.g. 01~12); the seventh and the eighth numbers represent the date (e.g. 01~31). The remaining numbers represent the time.

Increase or decrease the word by pressing Up or Down button. Long press Down to confirm and alternate to next parameter. After all the numbers are confirmed. Long press Down to enter the date and time.



9.3.4 Setting

This function is used for setting the inverter.



Password

The default password is **2014** for the installer, which only allows the installer to review and modify necessary settings complying to the local rules and regulations. If further advanced setting is required, please contact the distributor or us for assistance.

Press up or down button to increase or decrease the number. Long press Down to confirm and short press to alternate to the next number. After inputting the password, you can view the submenus of the setting parameters.




NOTICE!

- All the adjustable parameters including safety code, grid parameter, export control, etc. can be modified under the permissions of installer password. Unauthorized use of the installer password by unauthorized persons can lead to incorrect parameters being inputted, resulting in power generation loss or violation of local regulation.
- Replace the password with a new secure password for the consideration of account security.

9.3.5 Meter Energy

The user can check the import and export energy by this function. There are two parameters: **Total Import**, **Total Export**. Only when a meter or CT is installed in the system can the inverter accumulate the energy takes from or feeds into the grid. If there is no meter or CT in the system, the value will be 0. Press Up and Down to browse the values.




9.3.6 Error Logs

The Error log contains error information happened. It can record six items at most. Press Up and Down button to review parameter. Long press Up to return to the main interface.



9.3.7 About

This interface shows information of the inverter, including **Product SN**, **Register SN**, **Master**, **Manager** and **Internal Code**.



Item	Sub-item
QPowerLockEn	Enable
	Disable
	Pu_GridV1
	Pu_GridV2
	Pu_GridV3
	Pu_GridV4
	Pu_PowerRatio1
	Pu_PowerRatio2
	Pu_PowerRatio3
	Pu_PowerRatio4
	Pu_3Tau

Item	Sub-item
Q(u) Function	QPowerLockEn
	QuLockIn
	Qu_GridV1
	Qu_GridV2
	Qu_GridV3
	Qu_GridV4
	QuRatio1
	QuRatio2
	QuRatio3
	QuRatio4

9.4 Detailed Operation of Settings

Safety

The user can set the safety standard here according to different countries and grid tied standards. There are several standards for choice (May change without notice). In addition, the user has a **UserDefined** option which allows the user to customize relevant parameters within a wider range.




System will take effect according to the corresponding safety regulations.

Export Control

With this function the inverter can control the power exported to the grid. Whether having this function is based on user's wishes.

Choose **Disable** means the function will be shut off.


The user value set by installer must be within the range of 0 kW to 60 kW. Press Up and Down button to select and long press Down to confirm.



Grid Services

Usually end user do not need to set the grid parameters. All default value have been set before leaving factory according to safety rules.

If reset is needed, any changes should be made according to the requirements of local grid.



- **P (freq):** If reset is needed, any changes should be made according to the requirements of local grid.





Table 9-3 Items under **P (freq)**

Item	Sub-item
P (Over freq)	Enable
	Disable
	CurveType
	fULCO
	FreeDroopRate
	EntryDelayTime
	fPmin
	fhyste
	FreqStopPoint
P (Under freq)	Enable
	Disable
	fLLCO
	FreqDroopRate
	EntryDelayTime
	fhyste
	fPmax
	ExitDelayTime

- **Soft Start:** If reset is needed, any changes should be made according to the requirements of local grid.



- **Reactive Power:** If reset is needed, any changes should be made according to the requirements of local grid.




Table 9-4 Items under **Reactive Power**

Item	Sub-item
Off	-
Over-Excited	-
Under-Excited	-
PF(P)	PowerFactor 1
	PowerFactor 2
	PowerFactor 3
	PowerFactor 4
	PowerRatio 1
	PowerRatio 2
	PowerRatio 3
	PowerRatio 4
	EntryVolt
	ExitVolt
	PF(p)_3Tau

Item	Sub-item
Q(u)	Q(u) PowerLockEn
	Q(u)Lockin
	Q(u)LockOut
	Q(u)GridV1
	Q(u)GridV2
	Q(u)GridV3
	Q(u)GridV4
	QuQ1
	QuQ2
	QuQ3
	QuQ4
	Qu_3Tau
	mincosf
Fixed Q Power	Q Power

NOTICE!

- The terms shown in the interface depend on the local safety regulations.

- **P(u) Function:** This function is used to set the active power curve of the voltage.





Table 9-5 Items under **P(u) Function**

Item	Sub-item
P(u) Function	Enable
	Disable
	PuGridV1
	PuGridV2
	PuGridV3
	PuGridV4
	Pu_Ratio1
	Pu_Ratio2
	Pu_Ratio3
	Pu_Ratio4
	Pu_3Tau

- **PowerLimits:** User can set the power limit here. The setting value is between 0.00 and 1.10.



NOTICE!

- If local safety regulations provide otherwise, please follow the local safety regulations.

Grid Protection


Usually end user do not need to set te **Grid Protection**. All default values have been set before leaving factory according to safety rules.

If reset is needed, any changes should be made according to the requirements of local grid.

Table 9-6 Items under **Grid Protection**


Item	Description
O/V Stage1	Slow overvoltage point
U/V Stage1	Slow undervoltage point
O/V Stage2	Rapid overvoltage point
U/V Stage2	Rapid undervoltage point
O/V Stage3	Stage-3 rapid overvoltage point
U/V Stage3	Stage-3 rapid undervoltage point
O/V 10min En	10 min average overvoltage enabled
O/V 10min Set	10 min average overvoltage setting value
O/F Stage1	Slow overfrequency point
U/F Stage1	Slow underfrequency point
O/F Stage2	Rapid overfrequency point
U/F Stage2	Rapid underfrequency point
FreqROCOF	Rate of frequency change
H/LVRT Function	High/low voltage ride enabled
Frt_EnterVoltUp	Entry value of high voltage ride through
Frt_EnterVoltDn	Entry value of low voltage ride through
VacOVP1stTime	Stage-1 overvoltage protection time
VacOVP2ndTime	Stage-2 overvoltage protection time
VacOVP3rdTime	Stage-3 overvoltage protection time
VacUVP1stTime	Stage-1 undervoltage protection time
VacUVP2ndTime	Stage-2 undervoltage protection time
VacUVP3rdTime	Stage-3 undervoltage protection time
FacOFP1stTime	Stage-1 overfrequency protection time
FacOFP2ndTime	Stage-2 overfrequency protection time
FacUFP1stTime	Stage-1 underfrequency protection time
FacUFP2ndTime	Stage-2 underfrequency protection time

Item	Description
Connection	Parameter setting once inverter is powered on
Reconnection	Reconnection parameter setting after an error is triggered
VAC10MAvgT	10 min overvoltage detecting time
LVRT_O_Current	Low voltage ride through current enable




New Password

The user can set the new password here. We need to increase or decrease the number by pressing Up or Down button. Long press Down to confirm and alternate to next number. After the number is confirmed, long press Down to reset the password.



Communication

By this function, users can set RS485 communication, and shut down and power on of the slave inverter.



• RS485 CommAddr

If **Enable** is selected, the inverter will communicate with the computer, through which the operating status of the inverter can be monitored. When multiple inverters are monitored by one computer, RS485 communication addresses of different inverters need to be set. RS485 function will only be effective when the address is identical. The default address is **1**.



• ComLostShutDown

If **Enable** is selected, when the communication between the master inverter and slave inverters are loss for a certain period, the slave inverter will proactively stop generate power and stay in the waiting status.

This function is exclusive for parallel connection of inverters with DataHub or ModBus.



• ComBackPowerOn


When this function is turned on, when the communication between the master inverter and slave inverters is recovered, the slave inverters will be powered on.

This function is exclusive for parallel connection of inverters with ModBus.



ParallelSetting

When the user wants to use the parallel system with Modbus Function, enable this function and complete the settings, please refer to the instructions in section "14.3 Application of Parallel Connection". If not needed, disable this function.



GMPPT

There are 4 modes for selection: **Off, Low, Mid, High**. It shows the frequency of PV panel scan.

If **Low** is selected, the inverter will scan the PV panel by low frequency.

Time for Low: 4h; for Mid: 3h; for High: 1h.



Reset Energy

The user can clear the accumulated power energy of the inverter by this function.




Reset Meter

The user can clear the **Meter** and **CT** energy by this function. Press Up or Down button to select and long press Down to confirm. (The user can select Yes to reset meter if the user uses meters)



Reset Errorlogs

The user can clear the errorlogs by this function. Press Up or Down button to select and long press Down to confirm. (The user can select Yes to reset meter if the user uses meters)



Reset WiFi

The user can restart the WiFi by this function.




Machine Type

The user can check the **Machine Type** by this function.



Shutdown

By this function, users can realize remote shutdown function. Select **NO**, the inverter will shut down after short-circuiting; Select **NC**, the inverter will be powered on after short-circuiting.



10 Troubleshooting and Maintenance

10.1 Power off

- a. Turn off the AC switch between the inverter and the power grid.
- b. Turn off the external DC switch.
- c. Switch off the breaker, button, etc.



WARNING!

- After the inverter is powered off, there may still be residual electricity and heat which may cause electric shocks and body burns. Please wear personal protective equipment (PPE) and start maintaining the inverter at least five minutes after power off.

10.2 Troubleshooting

This section lists the possible problems with the inverter, and provides information and procedures for identifying and resolving them. In case of any errors, check for the warnings or error messages on the system control panel or App, and then refer to the suggestions below. For further assistance, contact Xwatt Customer Service. Please provide the model and SN of the inverter, and be prepared to describe the system installation details.

Table 10-1 Troubleshooting list

Error Code	Faults	Diagnosis and Solutions
IE:00001	TzFault	Over Current Fault.
		• Wait for about 10 seconds to check if the inverter is back to normal. • Disconnect the DC switch and restart the inverter. • Or consult us for solutions.
IE:00002	GridLostFault	Grid Lost Fault.
		• Check if the mains cable is loose. • Wait for a while and the system will reconnect when the utility is back to normal. • Or consult us for solutions.

Error Code	Faults	Diagnosis and Solutions
IE:00003	GridVoltFault	Grid Voltage Out of Range. • Check if the voltage of grid is out of range. • Or consult us for solutions.
IE:00006	GridFreqFault	Grid Frequency Out of Range. • Check if the grid frequency is out of range. • Or consult us for solutions.
IE:00009	PVVoltFault	PV voltage Fault. • Check whether the PV is overvoltage. • Or consult us for solutions.
IE:00010	BusVoltFault	DC Bus Voltage Out of Normal Range. • Check if the PV input voltage is within the operating range of the inverter. • Disconnect PV wiring and reconnect. • Or consult us for solutions.
IE:00012	GridVolt10MFault	Grid Overvoltage for Ten Minutes Fault. • The system will runs normally when the utility is back to normal. • Or consult us for solutions.
IE:00013	DclnJOCp	DCI Overcurrent Protection Fault. • Wait for a while to check if the inverter is back to normal. • Or consult us for solutions.
IE:00018	ResidualOCP	Overcurrent Protection Fault. • Check the connections of the inverter. • Wait for a while to check if the inverter is back to normal. • Or consult us for solutions.
IE:00020	IsoFault	Isolation Fault. • Check the connections of the inverter. • Or consult us for solutions.

Error Code	Faults	Diagnosis and Solutions
IE:00021	OverTempFault	Over Temperature Fault. • Check if the inverter and the ambient temperature exceeds the operating range. • Or consult us for solutions.
IE:00029	LowTempFault	Low Temperature Fault. • Check if the ambient temperature is too low. • Or consult us for solutions.
IE:00036	InternalComFault	Internal Communication Fault. • Restart the inverter to check if it is back to normal. • Update the ARM softusare or reburn the program. • Or consult us for solutions.
IE:00037	EepromFault	DSP EEPROM Fault. • Disconnect PV wiring and reconnect. • Or consult us for solutions.
IE:00038	RcDeviceFault	Residual Current Device Fault. • Restart the inverter. • Or consult us for solutions.
IE:00039 IE:00056	GridRelayFault	Relay Fault. • Check the grid connection. • Restart the inverter. • Or consult us for solutions.
ME:00103	Mgr EEPROM Fault	• ARM EEPROM Fault • Disconnect PV and grid. then reconnect. • Or consult us for solutions.
ME:00105	Meter Fault	Meter Fault. • Check the connection of the meter. • Check if the meter is in working order. • Or consult us for solutions.
ME:00101	PowerTypeFault	Power Type Fault • Check the version of ARM and DSP. • Check the product SN number. • Or consult us for solutions.

Error Code	Faults	Diagnosis and Solutions
ME:00104	Mgr Comm Fault	Mgr InterCom Fault • Shut down photovoltaic, and grid, reconnect. • Or ask for help from the installer if it can not return to normal.
IE:00016	SW OCP Fault	Software Overcurrent Protection Fault. • Wait for a while to check if the inverter is back to normal. • Disconnect PV and grid, then reconnect. • Or consult us for solutions.
IE:00028	Fan Fault	• Wait for a while to check if the inverter is back to normal. • Or consult us for solutions.

10.3 Maintenance

Regular maintenance is required for the inverter. Please check and maintain the following items based on the instructions below to ensure the optimal performance of the inverter. For inverters working in inferior conditions, more frequent maintenance is required. Please keep maintenance records.

 **WARNING!**

- Only qualified person can perform the maintenance for the inverter.
- Only spare parts and accessories authorized by Xwatt can be used for maintenance.

10.3.1 Maintenance routines

Table 10-2 Proposal of Maintenance

Item	Check notes	Maintenance interval
Fans	• Check if the fan makes noise or is covered by dust. • Clean the fan with a soft and dry cloth or brush, or replace the fan if necessary.	Every 12 months
Electrical connection	• Ensure that all cables are firmly connected. • Check the integrity of the cables, ensuring that there are no scratches on the parts touching the metallic surface. • Verify that the sealing caps on idle terminals are not falling off.	Every 12 months
Grounding reliability	• Check if the grounding cables are firmly connected to the grounding terminals. Use a ground resistance tester to test the grounding resistance from the inverter enclosure to the PE bar in the power distribution box.	Every 12 months
Heat sink	• Check if there are foreign objects in the heat sink.	Every 12 months
General status of inverter	• Check if there is any damage on the inverter. • Check if there is any abnormal sound when the inverter is running.	Every 6 months

10.3.2 Upgrading Firmware

WARNING!

- Make sure that the type and format of the firmware file are correct. Do not modify the file name. Otherwise, the inverter may not work properly.
- Do not modify the folder name and file path where the firmware files are located, as this may cause the upgrade to fail.

WARNING!

- Before upgrading, ensure that the PV input voltage is higher than 100 V (preferably on sunny day). Failure to meet this condition may result in upgrade process failure.

Upgrade preparation

- Prepare a USB drive (USB 2.0/3.0, ≤32 GB, FAT 16/32).
- Check for the current firmware version of the inverter.
- Contact our service support for the update firmware file, and save it to the USB drive.
 - » For ARM file: xxxxxxxxxxxx_X1_MINI_G4_PLUS_ARM_Vxxx.xx_xxxxxx.usb
 - » For DSP file: xxxxxxxxxxxx_X1_MINI_G4_PLUS_DSP_Vxxx.xx_xxxxxx.usb
- Check the folder name and file path:





Figure 10-2 Folder name and path

Upgrade steps

- a. Remove the dongle from the Dongle terminal of the inverter by hand, and then insert the USB drive. The inverter will automatically display the **Upgrade Selection** interface. (For the position of Dongle terminal, refer to "7.1.1 Terminals of Inverter".)
- b. On the **Upgrade Selection** interface, select **ARM** or **DSP** based on the file type, and then tap **OK**. Following the steps below to update the firmware.



 CAUTION!

- If the ARM upgrade fails or stops, do not unplug the USB drive. Power off the inverter, restart it, and then repeat the above upgrade steps.
- If the DSP upgrade fails or stops, please check whether the external DC switch is on, and the PV parameter is suitable for upgrading.

NOTICE!

- If the LCD screen lags or freezes after the upgrade, turn off the external DC switch, and then restart the inverter. Check if the inverter returns to normal. If not, contact us.

11 Decommissioning

11.1 Disassembling the Inverter



WARNING!

- Strictly follow the steps below to disassemble the inverter.
- Only use the dedicated removal tool delivered with the inverter to disassemble the AC connector.

Step 1: Disconnect the external AC breaker of the inverter.

Step 2: Break the PV connection.

Step 3: Turn off the AC breaker.

Step 4: Disconnect the PV connectors.




Figure 11-3 Releasing the PV connectors

Step 5: Slightly pull out the dongle module.

Step 6: Disconnect the AC connector: Insert the removal tool to the slot of the AC connector to release it. Slightly pull the connectors.




Figure 11-4 Use the AC terminal removal tool




Figure 11-5 Releasing the AC connector

- Step 7:** Disassemble the **COM/CT** port and slightly pull the RJ45 connector.
- Step 8:** Put the original terminal caps on the terminals.
- Step 9:** Unscrew the grounding screw by crosshead screw and remove the grounding cable.
- Step 10:** Unscrew the screw of the inverter. Vertically lift up the inverter to dismantle the inverter.




Figure 11-6 Unscrew the screw of the inverter

- Step 11:** Unscrew the screws for fastening the wall mounting bracket and remove the wall mounting bracket if needed.

11.2 Packing the Inverter

- Use the original packaging materials if available.




Figure 11-7 Packing the inverter

- If the original packing material is not available, use the packing material which meets the following requirements:
 - » Suitable for the weight and dimension of product
 - » Convenient for transportation
 - » Can be sealed with adhesive tape

11.3 Disposing of the Inverter

Properly dispose of the inverter and accessories in accordance with local regulations on the disposal of electronic waste.

12 Technical Data

- DC input

Model	XW-5.0K	XW-6.0K
Max. PV array input power [Wp]	7500	7800
Max. PV voltage [d.c.V]	600	600
Startup voltage [d.c.V]	50	50
Nominal input voltage [d.c.V]	360	360
MPPT voltage range [d.c.V]	40-450	40-450
No. of MPP trackers/Strings per MPP tracker	1	1
Max. PV current [d.c.A]	20	
I _{sc} PV array Short Circuit SC Current [d.c.A]	25	
Max. inverter backfeed current to the array [d.c.A]	0	

- AC output

Model	XW-5.0K	XW-6.0K
Rated output apparent power [VA]	5000	6000
Nominal AC output current [a.c.A]	21.7	26.1
Max. AC output current [a.c.A]	23.9	26.1
Max. output apparent power [VA]	5500	6000
Nominal AC voltage [a.c.V]/ Grid range	230; 90-300	
Nominal grid frequency [Hz]	50; ±5	
Displacement power factor	0.8leading-0.8lagging	
ITHDi (rated power) [%]	<3	
Current (inrush) [a.c.A]	50	
Maximum output fault current [a.c.A]	58 (15 ms)	
Maximum output overcurrent protection [a.c.A]	35	

• System Data, Protection and Standard

Model	XW-5.0K	XW-6.0K
Max. efficiency [%]	98	98
Euro. efficiency [%]	97	97
Standby consumption [W] @Night	<1	
Ingress protection	IP66	
Protective class	I	
Overvoltage category	II (DC), III (AC)	
Operating ambient temperature range [°C]	-25-60 (Derating at 45°C)	
Max. operation altitude [m]	<4000	
Humidity [%]	0-100	
Typical noise emission [dB]	25	25
Storage temperature [°C]	-30-70	
Dimensions(WxHxD) [mm]	330x235x145	
Weight [kg]	7.5	7.5
Cooling concept	Nature cooling	
Communication interfaces	CT/Meter/RS485	
Optional monitoring dongle	Pocket WiFi/4G	
Over/under voltage protection	YES	
DC isolation protection	YES	
Monitoring ground fault protection	YES	
Grid monitoring	YES	
DC injection monitoring	YES	
Back feed current monitoring	YES	
Residual current detection	YES	
Anti-islanding protection	YES	
Over temperature protection	YES	
SPD (PV/AC)	Type II	
Safety	EN/IEC62109-1/2	
EMC	EN61000-6-1/2/3/4; EN61000-3-2/3/11/12	
Grid monitoring	IEC61727	
Inverter typology	Non-isolated	
Active anti-islanding method	Frequency shift	

Technical Data

Model	XW-5.0K	XW-6.0K
Micro-breaker	32A	

13 Appendix

13.1 Application of Generator

13.1.1 Introduction of generator application

When utility power supply is unavailable, the system can seamlessly switch to the generator for power supply and continue the collaboration with the photovoltaic system to ensure the uninterrupted operation of the load.

In this case, the generator functions as the utility grid to supply power for the load, and the inverter converts the solar energy to electricity.

13.1.2 Notice for generator application

- Note 1: The generator should be equipped with an Automatic Transfer Switch (ATS), enabling it to start automatically in the event of a power outage.
- Note 2: The rated output power of the generator should be greater than the sum of the load power. If there are several inverters in parallel, the rated output power of the generator should be greater than the sum of the load power.

13.1.3 ATS control

In this operating mode, the generator functions as a substitute for the grid. There is no communication between the generator and the inverter, which means no wiring modifications are required (although the inverter cannot control the generator, either). The ATS working for the generator determines whether the generator should be turned on or off based on the status of the grid.

Wiring connection diagram




Figure 13-1 ATS control wiring diagram

Inverter settings for ATS

- a. Select **Settings > DryContact > Mode Select > Generator > ATS**.



13.2 Application of EV-Charger

13.2.1 Introduction of EV-Charger application

The EV-Charger is intended for charging electric vehicles. It should be installed in a fixed location and connected to the AC supply. The inverter can communicate with the smart EV-Charger to form an intelligent photovoltaic and EV charging energy system, thus maximizing the utilization of photovoltaic energy.

Wiring connection diagram




Figure 13-2 EV-Charger wiring diagram

Connection steps

Step 1: Plug one terminal of the communication cable to the right pin of the EVCharger and the other terminal to PIN 4 & 5 of the **COM/CT** port of the inverter.

Step 2: Connect the meter to PIN 4 & 5 of the **COM/CT** port of the inverter.

13.2.2 Setting for EV-Charger

Turn on the power of the entire system, enter the **Settings** page of the inverters on the LCD screen.

- a. Enter the **Export Control** page and chose **CT** or **Meter**.



- b. Select **EvChargerEnable** and then enter **Mode Select**. Ensure the interface shows **Enable** under **Mode Select**, which indicate the EVCharger function started successfully.



NOTICE!

- For specific wiring and setting procedures of EV-Charger, see *X1/X3-EVC Series User Manual*.

13.3 Application of Parallel Connection

The series inverter provides the parallel connection function, which could support several inverters to parallel in one system and can control zero injection to the grid with a meter installed in the main circuit. The parallel system can be achieved with Modbus Function.

13.3.1 Parallel System with Modbus Function

In this parallel system, at most 5 inverters can be connected. One inverter will be set as a master, and the rest are the slaves. The master inverter can communicate with all the slave inverters.

Wiring diagram




Figure 13-3 Wiring diagram-Parallel system with modbus function

NOTICE!

Before operation, please make sure that the inverters meet the following condition:

- All the inverters shall be the same series;
- The firmware version of all inverters shall be the same. Otherwise, the parallel function cannot be used.

Wiring procedure

- Step 1:** Connect all the inverters in the parallel system with each other via RS485 cables.
- Step 2:** Connect the communication cable with the master inverter.

Inverter setting for parallel system with Modbus function

Turn on the power of the entire system, enter setting page of the inverters on the LCD screen. Follow the instructions below to finish the settings.

- To set the master inverter:

- Enter **ParallelSetting** page, choose **Enable** to activate the function for the inverter.




- Make sure the meter/CT is connected to the master inverter. Enter the **Export Control** page and choose **Meter/CT** on the master inverter.



- Choose **M/S Mode** to select the Master inverter. Only one inverter can be set as **Master**.




- Set the value for **System Limit** on the master inverter. This will be the overall power limit for parallel system. The output power of slaves will then be distributed respectively according to their nominal output power. The value can be set within the range of 0 kW to 30 kW and the default value is 0 W.



- Set the parallel inverter number.



- Set the RS485 address.



- To set the slave inverters:

- a. Enter **Export Control** page, and the mode status is **Disable** by default (users cannot set by themselves).



- b. Choose **ParallelSetting** and then set the status of **Parallel Switch** as **Enable**.



- c. Enter **M/S Mode** and chose **Slave** to set the Slave inverters.

>M/S Mode
Slave

NOTICE!

- The power limit value set in **System Limit** is the limit for the multiple inverters in the parallel system, while the **UserValue** set in **Export Control** is the power limit for a single inverter which will be nullified when the parallel function is enabled.

Warranty Registration Form



For Customer (Compulsory)

Name _____ Country _____
Phone Number _____ Email _____
Address _____
State _____ Zip Code _____
Product Serial Number _____
Date of Commissioning _____
Installation Company Name _____
Installer Name _____ Electrician License No. _____

For Installer

Module (If Any)

Module Brand _____
Module Size(W) _____
Number of String _____ Number of Panel Per String _____

Battery (If Any)

Battery Type _____
Brand _____
Number of Battery Attached _____
Date of Delivery _____ Signature _____





XWATT ENERGY PRIVATE LIMITED

ADD.: Aji Industrial Estate, 80 Feet Road,
Rajkot, Gujarat, India 360003

E-mail: info@xwatt.in

Website : www.xwatt.in

